

Military Visualizations Inc.

Presents:

THE MILVIZ T-50 BOBCAT

“BAMBOO BOMBER”



MINIMUM REQUIRED SPECS:

THIS PRODUCT REQUIRES FSX AND/OR P3D FLIGHT SIM PLATFORMS. IT IS ALSO DESIGNED FOR NEWER SYSTEMS. MINIMUM REQUIREMENTS ARE A 2.6 CORE 2 DUO, 4 GIGS OF RAM, 512 MB VIDEO CARD AND 1.2GB OF FREE DISK SPACE. OPTIMAL REQUIREMENTS ARE AN I7 960 CPU, 8 GB RAM, 1 GB VIDEO CARD, (w/DX10-DX11), OR GREATER.

To obtain permission to post in the Milviz forum please send a request to: roadburner440@milviz.com

Milviz T-50 Bobcat

Model & Systems Testers

Mike Cameron

Beta Tester

Vassilios "Dimus" Dimoulas

Beta Tester

David "The Frog" Lawrence

Beta Tester

Steve "Slayer" McNitt

Beta Tester

Toby Wills

Beta Tester

Developers:

Collin Biedenkapp

MVAMS

Jonathan Bleeker

Cockpit Lighting

Chuck Jodry

Secondary Coder

Bill Leaming

3d Modeler and Gauge/Systems Programmer

Mike Maarse

Sound Environment

Rick Mackintosh

Materials/Livery Texture/ Beta Testing

Dutch Owen

Radio Range Sim & Flight Dynamics

Rich Petocz

User Guide Text & Design

3D Reach (<http://3dreach.com/>)

Model & Paint

Sergio "Raptor" Sanchez

Lights, Animations, FDE

Colin Pearson

Military Visualizations Inc.®

77 Mont Royal West, Suite 402

Montréal, QC

Canada • H2T2S5

¹ To obtain permission to post in the Milviz forum please send a request to: roadburner440@milviz.com

TABLE OF CONTENTS

Credits	2
Installation	4
LFR & Radio Range Navigation	5
Startup Procedure	7
Takeoff procedure <i>The T-50 Bobcat Idiosyncrasy</i>	12

T HIS PRODUCT IS AN ARTISTIC REPRESENTATION OF THE SUBJECT MATTER. MILITARY VISUALIZATIONS INC. DOES NOT ENDORSE AND IS NOT ENDORSED BY THE MANUFACTURER OF THE SUBJECT MATTER.

NOT ALL SYSTEMS HAVE BEEN SIMULATED AND THOSE WHICH HAVE BEEN SIMULATED ARE DONE SO USING THE LIMITATIONS OF THE MICROSOFT & PREPAR3D FLIGHT SIMULATOR PLATFORMS.

ANY INQUIRIES REGARDING COMMERCIAL, MILITARY OR ACADEMIC USE OF THIS PROGRAM SHOULD BE DIRECTED VIA EMAIL TO
info@Milviz.com

¹ To obtain permission to post in the Milviz forum please send a request to: roadburner440@milviz.com

Installation

If this is your first Milviz product, then you were introduced to the MVAMS when you completed the installation of the Milviz T 50 Bobcat. This system will always open first just after the installation and give you an opportunity to configure your aircraft just the way you want it when it opens in your flight simulator.

It's important to remember that you do not have to configure the aircraft at that moment. After the installation is complete, you'll see an icon for the MVAMS has been added to your desktop. Any time you wish, you can add, remove, and/or alter any of the options applicable to the aircraft you chose.


Installing the **Milviz T-50 Bobcat** is simple and no different than most other FS installations when it comes to 'pre-installation precautions'. These precautions include shutting down any programs that are open and disabling any active antivirus software.

After you've downloaded the **Milviz Bobcat** to your desktop, unzip and open the folder to find the **T-50 Bobcat** installer and then:

1. **Right-click** the installer from the resulting drop-down list and select "**run as administrator**". (A panel, similar to the one in the example below will open).
2. **Select** your simulator version and any options applicable to your needs.
3. (**Note:** figure 1 may reflect a slightly different configuration of options & selections, but essentially represents the installation selection panel for these choices.)

Repeat these steps if you wish to install the **Milviz Cessna T-50 Bobcat** in each additional flight-sim platform you have in your system.

Figure 1



3. **Finally**, remember to reactivate your antivirus and other security software that you disabled before you began the installation!

¹ To obtain permission to post in the Milviz forum please send a request to: roadburner440@milviz.com

LFR & Radio Range Navigation

Thank you for purchasing the Milviz T 50 Bobcat! Also known as the “Bamboo Bomber”, the Milviz team once again went as far as the flight simulator’s capabilities would let them. We’re sure that you’ll find it to be a very close recreation of the real-world T 50.

This user guide barely scratches the surface of the *Bamboo Bomber*’s operation and procedures. However, included in this user guide will be several links that we think you’ll find very interesting if not important.

In fact, during the time of the T 50s active service lifespan, they used a navigation system known as “LFR” (low-frequency radio range). This navigation system used a special combination of tones to tell the pilot which way he had to go in order to reach the airstrip he selected.

Of course, each airstrip of the day had a preassigned “Code”, Morse code Key, and frequency, which the pilot would listen for and follow, in order to maintain the correct heading to the destination.

This is an example of what information the Radio Range Frequencies table included:

(The Abbotsford, BC station is shown here)

ABBOTSFORD BC



T50 Bobcat

	Inbound	Outbound
Leg 1	151	331
Leg 2	249	69
Leg 3	330	150
Leg 4	69	249

Code: XA

Morse Code: -.- -.-

Frequency: 345 Kc

Airport: CYXX

Airport Details: CYXX R07

065M/4.3nm

Latitude: 49.0143°

Longitude: -122.4878°

Magnetic Variation: 20.8°

Please click on the following link for a complete, list of Radio Range Frequencies:

<http://smithplanet.com/fs2004/tools/rr/>

¹ To obtain permission to post in the Milviz forum please send a request to: roadburner440@milviz.com

A very clear and comprehensive tutorial has been prepared instructing exactly how this is accomplished. Please refer to this link:

- ♦ **FSX/P3D: Flying the Ranges in the Milviz T-50 Bobcat:**

<https://www.youtube.com/watch?v=ZQsINQ6qA5c>

It's an excellent, easy to understand, YouTube tutorial which includes an example using an actual Milviz T 50 flight!

Milviz also supplies a link which contains all the radio range frequencies for the airports that existed at the time the T 50 Bobcat was in service.

We strongly recommend that you first watch the YouTube tutorial, which will go over the entire process in detail. Then, refer to this link for your complete list of radio range frequencies assigned to the airports of the day.

- ♦ **Please click on the following link for the entire, complete, list of Radio Range Frequencies:** <http://smithplanet.com/fs2004/tools/rr/>

Included with this user guide, is the Pilot's hand book and several additional manuals that cover the operation of the T 50 Bobcat.

The Milviz T 50 installation package also includes a short but detailed, step-by-step procedure on the use of the MVAMS, (Milviz Add-On Management System).

The MVAMS user guide includes the procedure to reestablish your Flight Sim platform, (be it FSX or P3D based), to a default **Cold & Dark, (C&D)** or **Ready to Fly (RTF)** condition.

Upon opening a flight in your sim, you may find your aircraft engines running (or some systems on and active) even though you chose the **C&D** option in the MVAMS. If so, then you may need to return your flight simulator platform to its default "*Cold and Dark*" condition using the simulator's default aircraft, (preferably, the C172[†]).

It may be useful to know that following this procedure can also correct some anomalies (or *increasingly strange behavior* 🤖), that you may have been experiencing in your simulator lately. It's recommended that you bring your simulator to its default state periodically for that reason alone!

[†] Please note that the C172 FSX default aircraft would be the best selection for that platform. For P3D users, a similar aircraft comparable to the C172 will likely be the best selection as well. Please don't choose a more complex default aircraft for this procedure. Please refer to the MVAMS guide for detailed instructions.

Startup Procedure


The following pages will take you through the basic starting procedures of the Milviz Bobcat. In addition to these pages, you'll find the procedure in the "official" Bobcat manual included in this package. Alternatively, you can watch the YouTube tutorial, "*Starting the Milviz T-50 Bobcat*" by clicking on this link:

<https://youtu.be/Gj5yLseF0kw>

At the time of this User Guide's release, a previous version of the Bobcat startup video was still accessible here: <https://www.youtube.com/watch?v=6Y3txZxTgoY>. It's a more detailed tutorial than the other. However, it didn't include the Wobble pump step in the startup process. The tutorial was released before the decision was made to replicate the Wobble pump by the Milviz developers.

Of course, that step is included in the following pages of this user guide and the video in the first link, above.


1. After setting the Parking brake, **SWITCH ON MASTER BATTERY** (located just below the red-capped "Starter" toggle switch). You may notice that 'technically', that step comes farther down in the "Official" procedure. However, I find that doing it first is best, and particularly if you're doing the startup and need cabin and/or gauge lights on.



2. **SWITCH ON BOTH GENERATORS**
3. **CRACK THE THROTTLES ABOUT 10%** (carb air to "Cold")
4. **MOVE BOTH FUEL MIX LEVERS TO FULL RICH[†]**
5. **PROPS TO FULL FEATHERED (DECREASED RPM POSITION)**


[†]Contrary to many of today's aircraft with similar engines, in the Bobcat; The Mix lever's are in their *Full Rich* position when they're all the way 'back' (or down) as far as they'll go. In addition, the T-50's Prop levers are pulled back to their maximum feathered position when executing the startup instead of the more commonly seen, full forward position.

6. **ROTATE FUEL TANK SELECTOR [A] TO THE FULLEST TANK** (The Engine Fuel valve selector [B] for the Left, Right, & Both Engine selections as well as the 'Cross-feed' selector [C] are clickable & animated but are *In-Op* and have no effect).



7. **L-CLICK THE WOBBLE PUMP HANDLE AND HOLD THE MOUSE BUTTON DOWN UNTIL THE HANDLE RISES TO THE TOP OF ITS STROKE. THEN RELEASE THE MOUSE BUTTON AND THE HANDLE WILL RETURN TO ITS STARTING POINT.** This constitutes 'one full stroke'. Repeat this process until

the two Fuel Pressure indicator lamps extinguish. (typically, this takes about 11 to 13 strokes).



You'll notice that with each complete stroke of the Wobble pump, The Fuel pressure indicators in the gauges just above the indicator lights, will show an increase in pressure and as the indicators cross past the red line, the lamps will extinguish.



¹ To obtain permission to post in the Milviz forum please send a request to: roadburner440@milviz.com

Technically speaking, the step that follows the Wobble pump procedure would involve the operation of the **Primer Pump**. However, even though the Primer pump is animated when you roll the mouse wheel or click on it, this pump is not operational at present.

Therefore, you can move ahead to step 9 and ignore this step entirely if you wish.

That said, the Primer Pump procedure is included in this guide in case a future patch/update for the Milviz Bobcat is released and includes an operational Primer Pump[◇].


In case of that event, following this step in your startup process may be ‘good practice’.

8. USE MOUSE WHEEL TO ROTATE PRIMER PUMP TO YOUR LEFT OR RIGHT ENGINE (figure A).

Figure A THEN L-CLICK SEVERAL TIMES TO PUMP PRESSURE TO THE SELECTED ENGINE (figure B).



It will take approximately 4 to 6 full strokes to bring the fuel pressure up (as would be indicated by the fuel pressure gauges) and high enough to extinguish the FP lamp of the engine you're priming.




If our Bobcat Primer Pump was operational, this procedure would be repeated for the other engine after you followed through the steps and successfully started the first. Once both engines have been started, the Primer pump would then be returned to it's "OFF" position.

The entire 'Official' Startup procedure can be found in the "T-50 Bobcat_pilot_op_ins" PDF manual, included in the documents folder.

[◇] This is not to say that there are plans to make Primer pump operational but to suggest that it may happen. If and when it does, the Wobble Pump operation in step 7 will be edited to instruct a slightly different and somewhat more accurate application of its use.


¹ To obtain permission to post in the Milviz forum please send a request to: roadburner440@milviz.com

- 9. OPEN THE RED ENGINE STARTER COVER AND THEN L-CLICK & HOLD THE STARTER TOGGLE SWITCH TO 'DRY-CRANK' THE LEFT ENGINE[†] FOR A FEW REVOLUTIONS IN ORDER TO PUMP AND DISTRIBUTE SOME OIL EVENLY THROUGHOUT THE ENGINE.**



- 10. SWITCH ON THE LEFT ENGINE AND MAGNETO SWITCHES**
(in [figure D](#), Left engine selected)

Figure D



- 11. BE SURE THE FUEL MIX LEVER IS SET TO FULL RICH (as was instructed in step 4) AND THEN ONCE AGAIN, LEFT-CLICK & HOLD THE STARTER SWITCH. (the engine selected should start quickly & easily)**

[†] This example is starting the left engine first and therefore, Left-Clicking the switch. Alternatively, you would Right-Click & hold the toggle switch to start the right engine.

12. AFTER STARTING THE FIRST ENGINE, REPEAT STEPS 8 THROUGH 11 FOR THE REMAINING ENGINE.

13. FINALLY, RETURN THE PRIMER PUMP TO THE CENTER, “OFF” POSITION AND CLOSE THE STARTER SWITCH COVER.

Once the engines are both started, monitor both Engine Oil Pressure & Temp gauges ([Figure E](#)) and Cylinder Head Temp ([Figure E](#)) gage. Idle engines at 600RPM for about 30 seconds and then increase the RPM to approx. 800 - 900.

Ease the Propeller levers to their full forward, T/O position as soon as the oil pressure reaches 50PSI.

The Engine Oil Pressure should be between 60 & 80 PSI and the Oil Temperatures should attain 40C minimum before Take Off. The Cylinder Head temp should be 100C minimum.

Figure E



Figure F




¹ To obtain permission to post in the Milviz forum please send a request to: roadburner440@milviz.com

Takeoff procedure

The T-50 Bobcat Idiosyncrasy

If there's one thing most pilots who flew the T-50 would agree on, it's the way the Bobcat 'twists' to the left on take off. The following are some suggestions to counter that 'twist-factor'.

The instructions, (or really, more like suggestions), below are actually a compilation of suggestions from real-world pilots and the like. Some follow all the options given and others only follow a few. It's up to you to decide which, if any, you wish to try.



In the screenshot above, the T-50 is on its way down the runway as it gathers up speed for the T/O. It's depicting the position of the rudder which is obviously being applied to the right.

Of course, as the throttles are advanced, the characteristic becomes more prevalent, and this occurrence in itself is not really all that unusual. For many planes, the increasing torque on the engines will tend to 'twist' the aircraft in the opposite direction of the spinning prop. (Even some jet engines will do it but it's not as pronounced.)

However, for the T-50, this characteristic requires more than a little 'right-rudder' to correct. The use of the rudder to correct the problem must be combined with several other applications.

¹ To obtain permission to post in the Milviz forum please send a request to: roadburner440@milviz.com

Takeoff procedure (cont.)

To get right to it, you may find a combination of some or all of the suggestions in the list below helpful in keeping the aircraft running straight as it is attaining take-off speed.

Listed below, (and in the order that I personally found each option effective), are the application of throttle and rudder and how much of each to use, which you may find helpful. I can't stress enough that the order of this list is strictly my personal preference.

The content is taken from various, experienced, pilots, (both sim & real-world), which I then combined and tried out. Based on the experience I had with the Milviz T-50 Bobcat each time I took off, I found them to be very effective.

There are a number of variables and conditions that can significantly impact the effectiveness of these suggestions, such as, (but not limited to); weather, T/O altitude, barometric pressure & temperature, and of course, gross T/O weight of the aircraft.

UPON LINING UP ON THE RUNWAY'S CENTERLINE:

Throttle Control, (rudimentary application)

Gradually increase both throttles evenly and gently to get the plane rolling.

Rudder Control, (initial operation)

As the RPM of the engines and speed of the aircraft begin to increase, start applying right rudder and increase it as needed to keep the plane moving straight[♦].

Throttle Control, (Left throttle increase)

When the right rudder pedal approaches its maximum travel, continue to gently increase the left throttle but without increasing the right one (**Figure G** on the following page). Continue with the left throttle until you can reduce some right rudder application and still keep the plane on straight course (approx. 10% more left throttle than right). At that point, resume increasing both throttle levers simultaneously.

Rudder & Throttle control, (Combination)

The plane will be building speed and momentum and the rudder's control surface will begin to become increasingly effective. As it does, you'll begin to feel the plane's "cooperation" to stay straight on the runway. It's then that you'll gradually increase the right throttle to match the left.

Elevator Control

As the T-50 increases its speed allow it to 'decide' when to raise the tail off the ground. Try not to rush it with the elevator. The tail will rise in time when it's ready.

[♦] Some pilots found that applying right rudder trim along with right rudder pedal was sufficient to hold the aircraft straight and no more than that was needed. Others applied the use of ailerons to work in adjunct to the rudder and/or throttle manipulation.

Takeoff procedure (cont.)

As you could see on the previous page, the control of the throttles are important in assisting the rudder to correct the twist. This is particularly true when you first start off and the effectiveness of the rudder's control surface is negligible at best.

In that phase of the T/O, the rear wheel is probably handling 100% of the action to straighten up the aircraft. However, it won't be long before the aircraft reaches a speed fast enough to create a little lift and considerably reduce the traction and control of the rear gear.

Simultaneously, when the speed has increased to that point, that same speed also happens to be insufficient to offer much more than a 'breeze' across the rudder's control surface.

Hmmm.... That could problem.

Nevertheless, you're very resourceful, (and you've gotten used to waking up every morning), so you reach for alternatives. The list on the previous page for example.

One idea that may come to mind is to pull back on the yoke and try to keep some pressure on the rear wheel. That may not be of much help when you consider that the same speed was too slow to create enough airflow for the rudder's control surface. Therefore, the elevator may be just as handicapped as the rudder.

In the screenshot below, you'll note that the left throttle is ahead of the right throttle by roughly 10%, (give or take). This is something you may want to consider doing only seconds after you've started down the runway.

Figure G

Personally, I found it effective just so long as I advanced both throttles slowly, allowing the RPM to increase at a steady rate relative to the gradual increase in speed.



¹ To obtain permission to post in the Milviz forum please send a request to: roadburner440@milviz.com



To our Milviz customers who purchased the Milviz T-50 Bobcat prior to the inclusion of this user guide within the installer package:

I wish to offer my sincere apology to all and particularly those who may have experienced some difficulties and/or confusion due to my failure to have this User Guide prepared and available along with the other documents included with the Milviz T-50 installer upon it's initial release.

The late release was strictly the fault of the writer, (me), and I accept the full responsibility. I can only hope and ask that it isn't held against Milviz Inc. or its very talented team of developers, beta testers, and consultants.

This late release is atypical to my own personal expectations and goals and I will certainly strive to keep from letting it happen again.

Rick Petocz

¹ To obtain permission to post in the Milviz forum please send a request to: roadburner440@milviz.com